

"ULTIMATE" TURNOUT AND TIE PLATE LAYOUT GUIDANCE SHEET




PROTO:87 PROTOTYPICAL US # 7 TURNOUT based on Authentic AAR Dwgs

SCALE SPIKE HOLES SHOWN FOR NOMINAL CODE 70 BASE RAIL

USE THE 6" THICK BLACK REFERENCE BAR ABOVE TO VERIFY THE DIAGRAM IS PRINTED TO SCALE.

ALIGN PRE
VEE INTER
PROTO:87 F
ADJUST TC



Copyright Andrew Reichert 2003, 2005, 2008
Provided solely for customer assistance. See associated help sheets for additional instructions
All rights reserved. No whole, part, or derivative reproduction for commercial use, without express written permission.

tic AAR Dwgs


ALIGN PRE_FORMED FROG VEE POINT TO VEE INTERSECTION. F PLATES SHOWN IN PROTO:87 POSITION FOR BENT RAIL FROG. ADJUST TO RAIL ENDS FOR FINAL FIT

< HB > AND POINT HINGE

TIE LAYING TOOL EDGE SHOWN < NOMINAL 2" TRACKBED/CLEARANCE SPACE >

JOINT BAR MAY BE USED JOINT HINGE SLOT

ANGULAR DIVERGENCE POINT



instructions without express written permission.