


"ULTIMATE" TURNOUT AND TIE PLATE LAYOUT GUIDANCE SHEET

PROTO:87 PROTOTYPICAL US # 8 TURNOUT based on Authentic AAR Dwgs

SCALE SPIKE HOLES SHOWN FOR NOMINAL CODE 70 BASE RAIL

USE THE 6" THICK BLACK REFERENCE BAR ABOVE TO VERIFY THE DIAGRAM IS PRINTED TO SCALE.

ALIGN PRE_FORM VEE INTERSECTI PROTO:87 POSITI ADJUST TO RAIL



Copyright Andrew Reichert 2003, 2005, 2008
Provided solely for customer assistance. See associated help sheets for additional instructions
All rights reserved. No whole, part, or derivative reproduction for commercial use, without express written permission.

AAR Dwg


ALIGN PRE_FORMED FROG VEE POINT TO VEE INTERSECTION. F PLATES SHOWN IN PROTO:87 POSITION FOR BENT RAIL FROG. ADJUST TO RAIL ENDS FOR FINAL FIT

ID POINT HINGE

MAY BE USED : SLOT

LAR DIVERGENCE POINT

TIE LAYING TOOL EDGE SHOWN (NOMINAL 2" TRACKBED/CLEARANCE SPACE)



14.267

MULTIPLE SHEETS

TIE PLATE/PLANNING TOOL ENDS SHOWN (FOR PLANNING/ALIGNMENT)

tructions
out express written permission.